

-LAKELINE-

Part # W-PPS-RA-046

Installation of the Lakeline LLC Recoil System for Walther PPS M2 and Classic:

Supplies:

- Gun grease or oil.

Procedure

- Check that pistol is unloaded and remove magazine.
- Field strip the pistol, removing the slide and factory guide rod assembly per the factory user manual.
- Lube the Lakeline Recoil Assembly with a proper gun grease or oil and install. Reassemble the pistol.



- Check functionality, cycle the slide, lock it back, etc.

That's it! The only time it is required to disassemble the recoil assembly is to change springs. Heat can help to get the locking compound to release.

Thank you! If you have any questions or problems, the best way to contact us is by email at info@lakelinellc.com