

LAKELINE LLC

Lakeline Multi Red Dot Sight Mounting Plate Installation Instructions.

- Remove the rear sight. A sight pusher is recommended and there is often a screw or set screw that will need to be removed from the sight before pressing it out.
- Install the Lakeline Sight Mount in the dovetail. It is intended to fit tightly. That tight fit is what allows it to hold zero. Some fitting will be required. This can involve filing (with needle files), soft faced vices, etc. Either experience or a gunsmith is recommended to prevent damage to your pistol, the mounting plate, and/or the sight. Once you modify the plate, it cannot be returned so be sure it is a go before taking files, etc. to the plate. When pressed in place, it should be centered and look like:



- **Use extreme care when fitting the mount plate to an aluminum slide, like the TX22.** Modify the mount plate so it slides in snugly, but do it at least 1/3 of the way by hand, so as to not damage the pistol slide.
- **Apply medium thread locker to the sight screw or set screw hole and install the sight mount screw or set screw.**
- The Red Dot Sight may have been shipped with a Picatinny rail mounting plate already installed. Remove the 2 screws that hold the Picatinny mount on the red dot, and take it off first. Place the red dot sight on the Lakeline Sight Mounting Plate. The Vortex-Viper/Venom/Burris-Fastfire/Docter footprint sights will fit over the bosses on rear of the mount plate. The Trijicon RMR footprint sights fit over the bosses towards the muzzle side of the pistol.

- RMR style mounting:



- Vortex-Viper/Venom/Burris-Fastfire/Docter footprint sights:



- Putting a small piece of paper, wax paper is a good choice, between the red dot sight and the mounting plate makes it easier to remove the sight and will keep thread locker off of the red dot sight.
- The included screws are:
 - 2 Button Head Cap Screws - Provided for Vortex Viper and Venom Sights
 - 2 Flat Head Cap Screws - Provided for Burris FastFire and Docter Sights

There are many different sights, so use the screws that work best for your sight.

- The screws that are included with this mount require a 5/64" hex wrench and the set screw a 0.050" or 1/16" hex wrench for installation. **Check the screw lengths with your sight. On some sights, the screws may be a little long and need to be shortened.**



LAKELINE LLC

- Apply medium strength thread locker to the provided mounting screws that are correct for the sight you are mounting (usually the same style head as the sight uses for the Picatinny rail). Torque mounting screws to 15in-lbs max or the sight manufacturer's recommendations.
- No liability is expressed or implied for damage or injury which may result from improper installation or use of this product.

Thank you! If you have any questions or problems, the best way to contact us is by email at

info@lakelinellc.com