

LAKELINE LLC

K Series Grips Installation Instructions:

- Check that pistol is unloaded and remove magazine.
- Check one more time that pistol is not loaded.
- Remove 2 grip screws on each side, 4 total, and remove existing grips.
- Using the 4 screws, install new grips. Do not overtighten.



Thank you! If you have any questions or problems, the best way to contact us is by email at info@lakelinellc.com